



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.	ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	LW 001	GEAR CASE	1	33	LW 084	CASTER WHEEL	1
2	SM 500	DRIVE SPIDER	2	34	FE 246	POCKET WEIGHT	4
3	SM 015L	HELICAL GEAR LH	1	35	SM 016	HELICAL GEAR SHAFT	2
4	SM 015R	HELICAL GEAR RH	1	36	SM 036, SM 037	BEARING CONE, BEARING CAP	2
5	LW 002	GEAR CASE COVER	1	37	SM 088	MORFLEX COUPLING	2
6	LW 015	STOP SLIDE BAR	2	38	T2148	FLAT WASHER	4
7	LW 016C	HANDLE BAR SLOTTED RAIL	2	39	SM 491A	SPEED SHIFT TOOL PLATE	2
8	LW 017	HANDLE BAR TUBE	1		SM 192B	PLUG STONE TOOL PLATE	2
9	LW 019	LOWER SWITCH BOX BRACKET	1		SM 492-SP	UNIVERSAL TOOL PLATE	2
10	LW 020	UPPER SWITCH BOX BRACKET	1	40	LW 087	BOOSTER BOX HOLDER	1
11	LW 061	HANDLE BRACKET RH	1	41	SM 043, SM 037	BEARING CONE, BEARING CAP	2
12	LW 006A	HANDLE BRACKET LH	1	42	SM 072	HELICAL GEAR KEY	2
13	LW 014	INDEXING STOP	1	43	T 2012	WOODRUFF KEY	2
14	LW 032	COLLAR	1	44	X 048	TRANSFORMER	1
15	LW 070	POSITIONING ROD	1	45	SM 172	WATER HOSE BRACKET	1
16	LW 009D	HANDLE SLIDE BLOCK	2	46	LW 010	WATER VALVE LEVER	1
17	LW 031	STUD	1	47	LW 012	MOUNTING CLAMP	1
18	LW 033	PLASTIC KNOB	1	48	LW 018	WATER TANK LEVER	1
19	LW 008-SS	WATER TANK-STAINLESS	1	49	LW 029	HANDLE GUIDE	1
20	SM 091-ENCLOSURE	MAGNETIC STARTER	1	50	LW 11	WATER VALVE CLAMP	2
	FE 278	VARIABLE SPEED DRIVE	1	51	SM 174	WATER TANK VALVE	1
21	SMN 035	STATIONARY GUARD-MILD	1	52	T2003	HEX NUT	4
	SMN 035-SS	STATIONARY GUARD-STAINLESS	1	53	SM 457	Y-PIPE (DRY ONLY)	1
22	SM 442	DRY GUARD ASSEMBLY	1	54	SM 535	GUARD BRACKET	2
23	SM 320	LOWER CARRIAGE BRACKET	1	55	SM 536	GUARD STRAP	2
24	SM 319	UPPER CARRIAGE BRACKET	1	56	SM 322	FOOT PEDAL ARM	1
25	SM 349	7.5 HP, 1 PH, 230 V, 60 Hz MOTOR	1	57	SM 329	PIN	1
	SM 349A	7.5 HP, 3 PH, 240/415 V, 50 Hz	1	58	SM 328A	CARRIAGE PLATE	1
	SM 349B	7.5 HP, 3 PH, 230 V, 60 Hz	1	59	SM 327	PIN	1
	SM 349C	7.5 HP, 1 PH, 230 V, 50 Hz	1	60	SM 011B	TRUCK WHEEL SHAFT	2
	LW 055	5 HP, 1 PH, 220 V, 50Hz	1	61	SM 010	INNER BAERING CAP	2
26	SM 263	MOUNTING PLATE	1	62	SM 009	OUTER BEARING CAP	2
27	SM 057	HANDLE GRIP	2	63	SM 069, SM 070	BEARING CUP, BEARING CONE	4
28	LW 023R	BEARING CAP-RH	1	64	SM 008	TRUCK WHEEL	2
29	LW 023L	BEARING CAP-LH	1	65	SM 068	TRUCK WHEEL TIRE	2
30	SM 482	RISER PIN	4	66	SM 012	TRUCK WHEEL FELT WASHER	2
31	FE 248L	WEIGHT BASKET-LH	1	67	SM 323	FOOT PEDAL	1
32	FE 248R	WEIGHT BASKER-RH	1	68	T 2011	GREASE PLUG	1

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.	ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
69	SM 214	7.5 HP PINION	1	91	T2018	CAPSCREW	8
	LW 028	5 HP PINION	1	92	T2054	FLAT WASHER	15
70	LW 024	LOCK COLLAR	3	93	T2014	CAPSCREW	7
71	SM 182	COMPRESSION SPRING	1	94	T2003	HEX NUT	9
72	SM 326	UNDER CARRIAGE SPRING	2	95	T1024	CAPSCREW	4
73	SM 325	UNDER CARRIAGE SPRING	1	96	AH 026	GREASE ZERK	2
74	HBS 145B	SHOULDER BOLT	2	97	T2149	WROUGHT FLAT WASHER	4
75	LW 027A	SHOULDER BOLT	2	98	T2021	CAPSCREW	1
76	SM 169	GREASE SEAL	1	99	T2006	CAPSCREW	3
77	T2008	NYLON LOCK NUT	6	100	T1009	CAPSCREW	4
78	T1022	LOCK WASHER	2	101	T2057	SET SCREW	1
79	T1025	CAPSCREW	1	102	T3007	SET SCREW	3
80	T2004	CAPSCREW	8	103	T2130	CAPSCREW	9
81	T2116	SOCKET FLAT HEAD	6	104	T1055	SET SCREW	1
82	T1030	LOCK WASHER	22	105	SM 537	GUARD KNOB	2
83	AH 017	FILLISTER HEAD	14	106	T2029	CARRIAGE BOLT	2
84	SM 331	SNAP RING	2	107	HBS 196	HANDLE BAR KNOB	1
85	SM 230	SNAP RING	2	108	SM 186	HANDLE SPACER COLLAR	1
86	170	GREASE ZERK	7	109	T2082	COTTER PIN	1
87	SM 171	CAPSCREW	8	110	LW 064	DOWEL PIN	2
88	T1012	LOCK WASHER	16	111	SM 028	GUARD BRACKET	2
89	T1007	LOCK WASHER	10	112	SM 028L	LONG GUARD BRACKET	2
90	T1006	CAPSCREW	1	113	FE 098	SLOTTED TRUSS HEAD SCREW	4

PART NUMBER	DESCRIPTION	QTY.
SM 195	10-3 CABLE (501-S)	100'
T2145	8-3 CABLE (701-S)	100'
SM 206	MALE PLUG, 30A, 1 PH (501-S)	2
SM 207	CONNECTOR, 30A, 1 PH (501-S)	2
SM 420	MALE PLUG, 50A, 1 PH (701-S)	2
SM 421	FEMALE PLUG, 50A, 1 PH (701-S)	2
SM 424	MALE PLUG, 50A, 3 PH (701-S)	2
SM 425	FEMALE PLUG, 50A, 3 PH (701-S)	2
FE 207	VACUUM HOSE	
LW 078	BRUSH STRIP	
SM 456	DUST SEAL	1
LW 076	EMERGENCY STOP	1
SM 091-BUTTON	START/STOP (MAGNETIC ONLY)	1

