



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	FL 141	CLUTCH	1
2	FL 144	CLUTCH SPACER	1
3	FL 140R	CLUTCH MOUNTING BRACKET - RH	1
4	FL 140L	CLUTCH MOUNTING BRACKET - LH	1
5	FL 143	CLUTCH SPACER - ENGINE SIDE	1
6	FL 146	ENGINE MOUNT	1
7	T2151	SOCKET HEAD CAPSCREW	4
8	T1012	LOCK WASHER	4
9	FL 138	FRONT BELT GUARD	1
10	FL 148	IDLER BRACKET	1
11	FD 133	TAPER LOCK BUSHING	1
12	FE 052	PINION SHEAVE	1
13	FD 115	BEARING	2
14	X-34	SOCKET HEAD CAPSCREW	4
15	FL 136	MOUNTING PLATE	1
16	FL 134	TILT STOP	1
17	FL 151L	WEIGHT BASKET	1
18	FL 151R	WEIGHT BASKET	1
19	FL 011-MODIFIED	PINION	1
20	FL 135	PINION SHAFT	1
21	FD 100	KEY	1
22	T2081	SOCKET HEAD CAPSCREW	2
23	T2149	FLAT WASHER	4
24	SM 255	LOCK WASHER	4
25	T2150	HEX HEAD CAPSCREW	4
26	FE 215	IDLER BEARING	2
27	FD 129A	SHEAVE	2
28	FE 216	SNAP RING	2
29	T 2008	LOCK NUT	2
30	FE 213	IDLER SHAFT	1
31	T3021	SET SCREW	2
32	FE 300	WATER TANK - LP	1
33	FEN 14A	LP TANK BRACKET	1
34	FL 145	CLUTCH SWITCH	1

PART NUMBER	DESCRIPTION	QUANTITY
FL 142	25 HP ENGINE	1
FL 139	REAR BELT GUARD	1
FL 147	BELT	1